

Anlage 1: Kanalbelegung im Bereich Fernsehen

Bereich I:

Kanal	Frequenz/MHz	Programmname
2	47 - 54	
3	54 - 61	
4	61 - 68	

Unterer Sonderkanalbereich:

Kanal	Frequenz/MHz	Programmname
S 2	111 - 118	
S 3	118 - 125	
S 4	125 - 132	
S 5	132 - 139	
S 6	139 - 146	
S 7	146 - 153	
S 8	153 - 160	
S 9	160 - 167	
S 10	167 - 174	

Bereich III:

Kanal	Frequenz/MHz	Programmname
5	174 - 181	
6	181 - 188	
7	188 - 195	
8	195 - 202	
9	202 - 209	
10	209 - 216	
11	216 - 223	
12	223 - 230	

Oberer Sonderkanalbereich:

Kanal	Frequenz/MHz	Programmname
S 11	230 - 237	
S 12	237 - 244	
S 13	244 - 251	
S 14	251 - 258	
S 15	258 - 265	
S 16	265 - 272	
S 17	272 - 279	
S 18	279 - 286	
S 19	286 - 293	
S 20	293 - 300	

Bitte Rückseite beachten ==>

Erweiterter Sonderkanalbereich

Kanal	Frequenz/MHz	Programmname
S 21	302 - 310	
S 22	310 - 318	
S 23	318 - 326	
S 24	326 - 334	
S 25	334 - 342	
S 26	342 - 350	
S 27	350 - 358	
S 28	358 - 366	
S 29	366 - 374	
S 30	374 - 382	
S 31	382 - 390	
S 32	390 - 398	
S 33	398 - 406	
S 34	406 - 414	
S 35	414 - 422	
S 36	422 - 430	
S 37	430 - 438	
S 38	438 - 446	

Bereich IV/V:

Kanal	Frequenz/MHz	Programmname
21	470 - 478	
22	478 - 486	
23	486 - 494	
24	494 - 502	
25	502 - 510	
26	510 - 518	
27	518 - 526	
28	526 - 534	
29	534 - 542	
30	542 - 550	
31	550 - 558	
32	558 - 566	
33	566 - 574	
34	574 - 582	
35	582 - 590	
36	590 - 598	
37	598 - 606	
38	606 - 614	
39	614 - 622	
40	622 - 630	

Kanal	Frequenz/MHz	Programmname
41	630 - 638	
42	638 - 646	
43	646 - 654	
44	654 - 662	
45	662 - 670	
46	670 - 678	
47	678 - 686	
48	686 - 694	
49	694 - 702	
50	702 - 710	
51	710 - 718	
52	718 - 726	
53	726 - 734	
54	734 - 742	
55	742 - 750	
56	750 - 758	
57	758 - 766	
58	766 - 774	
59	774 - 782	
60	782 - 790	
61	790 - 798	
62	798 - 806	
63	806 - 814	
64	814 - 822	
65	822 - 830	
66	830 - 838	
67	838 - 846	
68	846 - 854	
69	854 - 862	

Bitte Rückseite beachten ==>